






**DoAll Vertical Bandsaw (white) and Dayton Vertical Bandsaw (black)**



Operation of the two vertical bandsaws is similar





To raise or lower the BLADE GUARD  
first

**UNLOCK**

(counterclockwise)

the guard,

then

**ADJUST THE HEIGHT**

(clockwise RAISES,  
counterclockwise LOWERS)

so that your work

just fits

under the guard,

then

**LOCK**

the blade guard.